



How to Clean the Dyson DC14 Internal Channels

This guide will instruct you on cleaning the internal channels of your vacuum.

Written By: Donald Percivalle



INTRODUCTION

The internal channels of your vacuum can become dirty with use. They do not need to be cleaned often, but doing so can result in quieter operation as well as less dust in the exhaust of the vacuum.



TOOLS:

- [Shop Towels or Rags](#) (1)
 - [Compressed Air](#) (1)
-

Step 1 — How to Clean the Dyson DC14 Internal Channels



- ❗ The channels that become dirty with dust are in the canister of your vacuum.
- Start with the canister of your vacuum.

Step 2



- Turn the canister around and locate the latch that secures the outer housing of the canister to the cyclone assembly, and push it upwards.
- Now, free the cyclone assembly from the clear, plastic canister housing.

Step 3



- Clean the inside of the cyclone assembly out. Use a cloth to clean; the more dust you can clear the less dust will end up in the exhaust of your vacuum.
- ⓘ If you have an air compressor, don't be afraid to use it to blow the dust out of all the nooks and crannies of the cyclone assembly. This is a very sturdy component, and the strong air currents will not damage it.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-08-24 12:40:16 AM.